

**Comfort Harness
Assembly**

Version 1.1, February 1, 2014

Disclaimer

This document is proprietary to Scubatech Sp. z o. o. ("Scubatech") and no ownership rights are hereby transferred. No part of this document shall be used, reproduced, translated, converted, adapted, stored in a retrieval system, communicated or transmitted by any means, for any commercial purpose, including without limitation, sale, resale, licence, rental or lease, without the prior express written consent of Scubatech.

Scubatech does not make any representations, warranties or guarantees, express or implied, as to the accuracy or completeness of the manual. Users must be aware that updates and amendments will be made from time to time to the manual. It is the user's responsibility to determine whether there have been any such updates or amendments. Neither Scubatech nor any of its directors, officers, employees or agents shall be liable in contract, tort or in any other manner whatsoever to any person for any loss, damage, injury, liability, cost or expense of any nature, including without limitation incidental, special, direct or consequential damages arising out of or in connection with the use of the manual.

Should you have any questions or comments regarding this manual, please contact:

Scubatech Sp. z O.O.

Ul. Lubieszńska 2
72-006 Mierzyn
Poland

Tel/Fax: +48 91 453 00 17

Mobile: +48 605 662 795

Email: scubatech@scubatech.pl

Web: www.scubatech.pl

Table of Contents

- Disclaimer 2**
- Scope of Delivery 4**
- Assembly 4**
 - Step 1 - Installing the Shoulder Belt 4
 - Step 2 - Installing the Right Shoulder Pad 4
 - Step 3 - Installing the Right Pull Ring 5
 - Step 4 - Installing the Pull Belt 6
 - Step 5 - Installing the Left Shoulder Pad 8
 - Step 6 - Installing the Crotch Strap 9

Scope of Delivery

The Tecline comfort harness is delivered as a complete set, ready for assembly:

Parts of the comfort harness



Unlike a standard harness, the comfort harness consists of 3 main belts + crotch strap. These parts are assembled as follows.

Assembly

Step 1 - Installing the Shoulder Belt

- First, insert the belt part with the grommet from the back side of the plate through the left and right angular slots.
- The grommet must remain centered over the backplate hole.



Step 2 - Installing the Right Shoulder Pad

- Hold the right shoulder pad in front of the backplate, so the Tecline logo faces away from it.
- Lead the right part of the shoulder belt through the top flap in the shoulder pad and then back through the upper horizontal slot in the backplate.



- Flip the right part of the shoulder belt forward, and lead it through the second flap in the shoulder pad.



- Below the Tecline logo, there are 3 more flaps in the shoulder pad. Lead the right part of the shoulder belt through the first flap.
- Install a bent D-ring above the middle flap.
- Lead the shoulder belt through the third flap.



Step 3 - Installing the Right Pull Ring

- Lead the belt up through the moving part of the pull ring and then through the pull ring itself.



- Lead the belt back through the shoulder pad, the way it came down (through the third flap, through the D-ring and through the first flap).
- You might need to use a pair of pliers to pull the belt through the D-ring again.



- Finally, hide the belt end under the flap with the Tecline logo.




Step 4 - Installing the Pull Belt

- Turn the belt, so the seam faces downwards.



- Lead the end of the pull belt upwards through the pull ring, over the cross strut.




- Then, lead the belt end downwards through the moving part of the pull ring.




- Install the two rubber pieces to support a backup lamp.



- Lead the belt end through the inner backplate slot at the bottom.



- On the back side, fix the belt with a tri-glide and lead it through the outer slot.



Step 5 - Installing the Left Shoulder Pad

- Mount the shoulder pad on the left shoulder belt, as described in step 2.
- Lead the belt through the second flap, and install the inflator bungee.



- Install the angular D-ring, the pull ring and the pull belt like on the right side.



- Install two rubber pieces on the pull belt.
- Lead the pull belt through the slots at the bottom (with fixation).




Install the movable D-ring.

- Install the buckle.



Step 6 - Installing the Crotch Strap

- Install the remaining rubber piece on the belt.
- Lead the belt end upwards through the horizontal slot at the bottom of the backplate (from back to front).
- Lead the belt end through the rubber piece, through the backside D-ring and back through the rubber piece.



Adjust the harness to the diver, by pulling the left and right belt through the tri-glides on the back.

Should the belt be too long, you may cut it to length. In this case, be sure to melt the cutted belt edge with a lighter, in order to avoid fraying.

You may also fold back the overlapping belt end to the left and secure this end to the belt with duct tape.